
HD DTA CONVERTER CONNECTIONS



The preferred connection for your HD DTA is through an HDMI cable. It will provide the best high-definition picture and Dolby Digital sound. You may also use a Coax cable for standard-definition picture and stereo sound.



Visit **buckeyebroadband.com** for additional information.

419.724.9800 • NW Ohio/SE Michigan 419.627.0800 • Erie County

This document has attempted to include the most recent and accurate information as of the date of publication, it is subject to change without notice.

CONVERTER CONNECTION GUIDE





DVR/HD CONVERTER VIDEO CONNECTIONS


VIDEO CONNECTIONS

HDMI and Component Cables will provide the best quality HD picture. Composite or S-Video will provide a clear picture, but it will not be highdefinition.

Note: You may also use a Coax Cable for standard-definition picture and stereo sound.

DVR/HD CONVERTER TO TV (NOT AVAILABLE ON ALL CONVERTERS) VIDEO COMPONENT VIDEO HDMI OUT S-VIDEO COAX CABLE FROM OUTLET (CABLE IN DVD/BLU-RAY COMPONENT VIDEO HDMI IN номі очт (COMPOSITE VIDEO S-VIDEO COAX (F-CONNECTOR) COAX/ANTENNA IN HDMI CABLE S-VIDEO

DVR/HD CONVERTER AUDIO CONNECTIONS



AUDIO CONNECTIONS

For the best possible picture and sound quality, we recommend using the HDMI cable that comes with your converter. If your TV does not support HDMI, you may use Optical Audio for high-quality Dolby Digital sound or Composite Cables for stereo sound.

Note: You may also use a Coax Cable for standard-definition picture and stereo sound.